



Print out PDF file.

Glue to cardboard cereal box.

Cut out panels (as accurately as possible)

Tape the ends of the panels together (one side at a time)

Pull the panels together as you tape to the bow.

Join the two halves together at stern.
Tape from stern to bow pulling edges in.
Align top panel edges at bow and tape.
Align "tick" marks on stern panel and tape.
Place "bulkhead" on dashed line and tape.

